

FIG. 1A

FIG. 1B

0968303-10100




FIG. 2

096303-10110




FIG. 3

FIG. 4A

72	72	72	
SYMBOL	SYMBOL	SYMBOL	
SYMBOL	SYMBOL	SYMBOL	
SYMBOL	SYMBOL	SYMBOL	76

FIG. 4B

SYMBOL	SYMBOL	SYMBOL	74
SYMBOL	SELECT SYMBOL	SYMBOL	78
SYMBOL	SYMBOL	SYMBOL	

FIG. 4C

SYMBOL	SYMBOL	SYMBOL	74
SYMBOL	SELECT SYMBOL	SELECT SYMBOL	78
SYMBOL	SYMBOL	SYMBOL	80

FIG.4D





FIG. 4E



The image is a technical drawing of a slot machine interface, specifically for a game titled "STOOGES-O-VISION". The machine features a 5x3 grid of reels. The symbols on the reels include the faces of the Three Stooges (Moe, Larry, and Curly), a "BONUS BETTER" sign, and the text "WHEELIE HEADS". Above the reels is a banner that reads "CURLY-IN-THE-MIDDLE BONUS PICK MOE OR LARRY". Below the reels is a control panel with a coin slot, a "CASH OUT" button, a "HELP" button, a "STOP SPIN" button, and a display showing the number "468". The machine is labeled with reference numerals 72, 86, 90, 78, 80, and 76.

Fig. 5A

The illustration shows a slot machine with a 3x5 grid of symbols. The symbols include Curly Howard, Moe, and Larry, as well as 'NUTTY HEADS' and 'HEY MOE' text. The machine has a top banner that reads 'CURLY-IN-THE-MIDDLE BONUS'. The bottom control panel includes buttons for 'FAST BET', 'HELP', 'STOP SPIN', and 'MAX BET'. The central display area shows the current bet and total bet. Handwritten numbers 72, 86, 88, 74, 82, and 76 are placed around the machine to indicate specific components.

Fig. 5B

09585300-101100




Fig. 5C

09586308-101100




Fig. 5D

09686308-101100




Fig. 5E

09586308.101.100





Fig. 5F

096808-10



F.g. 5G